


Float Arrangement Diagram



Oreco Systems®
Incorporated

Check the appropriate box for the float function (color code) used in your system.



Float Types

- Typical OSI float model: A
- Specs: contact - normally open
differential - no minimum
power rating - signal
- Possible substitutions: B, C, D

814 AIRWAY AVENUE

SUTHERLIN, OREGON

97479-9012

TELEPHONE:

(541) 459-4449

FACSIMILE:

(541) 459-2884

Control Panel Series

MVP-DAX PT

Drawing No.

EDW-FA-DAX-22

EDW-FA-DAX-22
Rev 2.0 © 02/14/01