Control Panel Wiring Diagram Model MVP-S1/2 DM SA




FACSIMILE:

(541)459-2884


WEB SITE:

www.orenco.com





Removal of the terminal link rail will separate the high level alarm and override timer functions.





*Options = Heater = Power Light PRL = Pump Run Light

For MVP-S operation description, see drawing no. "EIN-CP-OP-2036".

