## Float & Splice Box Wiring Diagram

For use in two pump systems, discharge side.

**Splice Box Wiring** 



814 AIRWAY AVENUE

SUTHERLIN, OREGON

97479-9012


TELEPHONE:

(541) 459-4449

FACSIMILE:


(541) 459-2884





## **Float Types**





Y - Yellow

R - Red

- Purple

n - Orange

- Blue

E - Grev

W - White Green Note: Multi-function floats will have

more than one marker

**Attention:** Failure to follow splicing instructions will void warranty

\* Refer to drawing EIN-SB-SB-1 for splicing instructions.

**Control Panel Series** 

**Float Function Color Code** 

Splice Box Model

Drawing No.

**VCOM-AXB/PT** /(YG)RW

SB4

EDW-FS-AX-4

White Wire

Green Wire

Waterproof

Heat Shrink &

Butt Connector \*

Wire Nut

EDW-FS-AX-4 Rev 1.1 © 03/15/04