

# Panel Wiring Diagram Model MVP-DAX1 PT




Oreco Systems<sup>®</sup>  
Incorporated



814 AIRWAY AVENUE  
SUTHERLIN, OREGON  
97479-9012

TELEPHONE:  
(541) 459-4449

FACSIMILE:  
(541) 459-2884



NOTE: Motors must have internal overload protection



- ### Key
- = Factory Wire
  - = Field Wire
  - - - = Alternate Field Wire
  - AL = Alarm Light, 115 VAC
  - AS = Audio Silence Switch
  - CCB = Controls Circuit Breaker
  - Logo = Logic Module
  - M = Motor Contactor
  - PCB = Pump Circuit Breaker
  - TL = Terminal Link
- \*Options**
- HT = Heater
  - PL = Power Light
  - PRL = Pump Run Light

For MVP-DAX operation description, see drawing no. "EIN-CP-OP-513".

