

# Control Panel Wiring Diagram

## Model VCOM-S1 RO



814 AIRWAY AVENUE  
SUTHERLIN, OREGON  
97479-9012

TELEPHONE:  
(800) 348-9843  
(541) 459-4449

WEBSITE:  
www.orenco.com


### Key

- = Factory Wire
- - - = Field Wire
- · - · = Alternate Field Wire
- A = Audio Alarm, 115 VAC
- AL = Alarm Light
- AS = Audio Silence Switch
- CCB = Controls Circuit Breaker
- DF = Fuse, 120VAC/1A
- M = Motor Contactor
- PCB = Pump Circuit Breaker
- PSA = Phone Line Surge Arrester
- PSC = Power Supply Cord (24VDC)
- RTU = ATRTU-100 Controller
- TL = Terminal Link
- TR = Transformer 120-36/18VAC

### \*Options

- HT = Heater
- PL = Power Light
- PRL = Pump Run Light
- SA = Surge Arrester

### Remote Alarm Connections




### Terminal Block Types




For VCOM-S RO operation description, see drawing no. "EIN-CP-OP-498".

### Power Wiring Options




Factory default. Wire as shown.

Use one wire nut to connect the pump and controls circuit breakers together with the incoming L1 power line. Use another wire nut to connect the pump and controls neutral blocks together with the incoming neutral line.



For float arrangement diagram, see drawing no. "EDW-FA-S-34".

### Telephone Line Connection



NOTE: Motors must have internal overload protection